


## 12 PIN CARAVAN SOCKET

|    |                            |                                   |
|----|----------------------------|-----------------------------------|
| 1  | LEFT HAND INDICATOR        | YELLOW                            |
| 2  | SPARE                      |                                   |
| 3  | GROUND / EARTH             | BLACK                             |
| 4  | RIGHT HAND INDICATOR       | GREEN                             |
| 5  | SERVICE BRAKES             | BLUE OR RED                       |
| 6  | STOP LIGHTS                | RED                               |
| 7  | CLEARANCE LIGHTS           | BROWN                             |
| 8  | SPARE                      |                                   |
| 9  | AUX / HYDROLIC DISC BRAKES | RED (6B&S) / SWITCHED / INGNITION |
| 10 | RETURN EARTH               | (6B&S)                            |
| 11 | SPARE                      |                                   |
| 12 | BREAKSAFE MONITOR          | PURPLE (NSW requirement only)     |



## 12 PIN FLAT SOCKET

50 AMP ANDERSON (GREY) TO CHARGE HOUSE BATTERIES (3B&S CABLE MINIMUM REQUIREMENT) SWITCHED  
 50 AMP ANDERSON (RED) FOR ALKO ESC (ONLY IF ALKO ESC IS FITTED) (6mm CABLE MINIMUM REQUIREMENT)